

To start your SC press 1s

To stop your SC press 3s

To start the Timer press shortly
(a record start automally)

To synchronise the timer to the next
minute, press shortly .

To go back into the Menu
screen presentation,
or
to validate a new value
for any setting,
press shortly

To stop the timer,
To stop the chrono,
To stop a record
press shortly

To set the timer
To the value you want,
or To reset the Timer to its default value
press shortly

Used to go upwards in the Menu screens

In MULTI/RACE SCREEN MODE, press UP to loop backwards
the displayed information on the top side of the screen.
(screen size 1/1 - 1/2-1/2 or 2/3-1/3)
Press longly to come back to the previous information

When setting a value, press UP to increase this value.

In Menu screen presentation,
press shortly to validate
your choice and to enter
in the selected setting

Press on MODE to change
the display mode of your screen
1 information full size
2 information, half size each
2 information 2/3-1/3

Used to go downwards in the Menu Mode

In MULTI/RACE SCREEN MODE, press DOWN to loop backwards
the displayed information on the bottom side of the screen.
(screen size 1/2-1/2 or 2/3-1/3)
Press longly to come back to the previous information

When setting a value, press DOWN to decrease this value.

